

The Infinity **IN-USB-1** and **IN-USB-2** foot pedal is fully compatible with all Microsoft Windows Versions & Apple Macintosh. Make sure the transcription software (not included) you are using is compatible with your operating system.

### ***Installing the IN-USB-1 or IN-USB-2 Foot Pedal on Windows 2000, XP or Vista:***

Plug the **IN-USB-1** or **IN-USB-2** foot pedal directly into an open USB port on your PC. The foot pedal will be recognized automatically as long as your PC has full USB support.

### **General Installation Information:**

- Download and install transcription software (NOT INCLUDED)
- Reboot computer
- Plug in the IN-USB-1 or IN-USB-2 foot pedal to an available USB port on your computer
- If computer does not recognize foot pedal try another available USB port

### ***Installing the IN-USB-1 or IN-USB-2 on Windows 98:***

The Add New Hardware window will prompt you to install the drivers for the new device. Choose "Search for the best driver for your device." Windows will now ask you where to search for the device drivers. Choose "CD-ROM drive" and insert the Windows 98 CD into the computer's CD-ROM drive. Then click "Next". Follow the instructions on screen. Support for the USB device should now be installed.

Note: USB is not supported by Windows NT or by most releases of Windows 95. USB ports on PCs that are more than 4 years old may be of too low a voltage to recognize an un-powered device like a foot pedal.

### ***Installing the IN-USB-1 or IN-USB-2 on Apple Macintosh:***

Contact the manufacture of your Apple Macintosh transcription software program for installation instructions.

### **ECS has a free utility to test either the IN-USB-1 or IN-USB-2 foot pedal at:**

[www.tvps.com/ecsdnloads/power testers setup.exe](http://www.tvps.com/ecsdnloads/power testers setup.exe)